



**Installation Instruction
Top Slider 87-05 Wrangler**

P/N 12701.XX
P/N 12702.XX

IMPORTANT NOTICE:

Carefully read all instructions before installing this product. Rugged Ridge is not responsible for any damage to the vehicle or personal injury that may occur during the installation or use of this product.

WARNING!

This product is not designed to be relied on for containment of occupants within the vehicle or against injury during an accident. This product is to be used as an enhancement to the appearance of the vehicle and only to protect occupants from the elements.

WEAR SEAT BELTS AT ALL TIMES

INCLUDED PARTS

QTY	DESCRIPTION
2	Top Sliders (Driver and Passenger)
2	Latch Hooks
	Latch Handles w/ Hardware
2	(Installed)

INSTALLATION INSTRUCTIONS

- (1.) Position the front pin of the upper door slider in the front factory door insert.
(See fig. 1)
- (2.) Allow the upper door slider to drop into position and that pins are well seated.
(See fig. 2)
- (3.) Close door to test for fitment. **NOTE:** If slider does not fit correctly, you may tilt the slider front to back until it seats properly.
- (4.) For 1987-1995 Wranglers insert plastic strip on bottom of slider into factory channel located on the lower half door, and secure front door snap.
- (5.) With upper door sliders installed, take the latch hooks and attach to the pre-installed latch handles. To install latch hook, slide one pin fully and press in to engage.
NOTE: Be careful not to break pins when engaging. Slide windows in open positions to help ease installation. Repeat steps for other side.
- (6.) Close and test latch hooks. Squeeze the release button and slide window open.
(See fig. 3)

Fig.1



Fig.2



Fig.3



LIMITED 90 DAY WARRANTY
Applies to Rugged Ridge by Omix-ada Inc. Products

Rugged Ridge Off Road (the Company) warrants to the original purchaser of this product that should the product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 90 DAYS from the date of original purchase, such defect(s) will be repaired or replaced or credited at the Company's sole option.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. Dated bill of sale), specification of defect(s) to the place of purchase or, with prior approval from the Company (Return Authorization Number is required), freight pre-paid to the Company address listed below.

This warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident or by acts of nature. THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN THE PERIOD OF 90 DAYS FROM DATE OF ORIGINAL PURCHASE.

IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some States do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Omix-ada Inc.
460 Horizon Dr. Suite 400
Suwanee, Georgia 30024